



WARTMANN®

HOT AIR FRYER



PURE & FRESH

Enjoy a delicious steak, fish, vegetable or potato dish. With the Wartmann® hot air fryer you'll cook crispy chips from fresh potatoes, with only a few drops of vegetable oil, in just 20 minutes.

The Wartmann® hot air fryer is not just great for grilling a piece of meat or fish, but you can also use it to prepare your favourite snack. From now on you'll serve the most delicious fried dishes!

VERSATILE & MODERN

The Wartmann® hot air fryer has built in seven pre-set menu's. The digital touch screen allows you to operate the Wartmann® hot air fryer with the tip of your fingers.

Temperature and cooking time can be manually adjusted to suit your personal preferences.

The optionally available Wartmann® hot air fryer accessory set includes a cake tin, a fish grill pan and six cupcake moulds.



POWERFUL & COMPLETE

The Wartmann® hot air fryer beeps when your dish is ready and will automatically turn itself off. If you want to interrupt a cooking program, for example to check your fries, then the program automatically restarts where you left it. With 1400 watts and a content of 3.2 litres the Wartmann® hot air fryer is suitable for every cooking task.

The Wartmann® hot air fryer has a recommended retail price of € 149.95 and is available in black (art.nr. 225073), white (art.nr. 225074) and red (art.nr. 225075).

